


# Improved QUICK START GUIDE Digital TV (DVB-S2-T2-C) for the DENSON DEN22\_24TVSMART.

## FIRST TIME START-UP NEW OUT OF THE BOX:

The 22 and the 24TVSMART start up in SATELLITE TV (DVB-S) mode with the Preset GERMAN Free To Air channel list:

After turning ON the Smart TV, you will see "NO SIGNAL" on the screen, provided the dish is not pointed at the ASTRA-1. (If you have aligned the dish on Astra-1 when turning on the TV, then you have a picture of a German Free To Air channel).

### 1. CANAL DIGITAAL FASTSCAN channel download on Astra-3 (23.5° East):



2. Use the MENU button on the Remote control.
3. You enter the Main menu of the Satellite TV, go to INSTALLATION and use OK button.
4. In menu Installation: Go to AUTO SEARCH and use the OK button.
5. Select at COUNTRY > NETHERLANDS
6. Select at SCAN MODUS > FASTSCAN.
7. For OPERATOR automatically CANAL DIGITAAL occurs.
8. Go to SEARCH and use the OK button and the FastScan channel download starts.



### 2. TV VLAANDEREN or TELESAT FASTSCAN channel download on Astra-3 (23.5° E) or HOTBIRD (13° E):

9. Follow point 2. & 3. mentioned above.
10. You enter the Main menu of the Satellite TV, go to INSTALLATION and use OK button.
9. In menu Installation: Go to AUTO SEARCH and use the OK button.
10. Select at COUNTRY > BELGIUM.
11. Select in SCAN MODUS: FASTSCAN.
12. For OPERATOR automatically TV VLAANDEREN occurs.
13. For the TELESAT channels change in OPERATOR TV Vlaanderen in TELESAT with the ► button.
13. Go to SEARCH and use the OK button and the FastScan channel download starts.



You can now watch and listen to the required TV & Radio channels. Have much fun!

If you now want to set up the SMART TV, please refer to pages 9 to 13 of the user manual.

## QUICK START GUIDE TERRESTRIAL TV (DVB-T) & CABLE TV (DVB-C) for the Full HD DENSON DEN22/24TVSMART

### FIRST TIME START-UP NEW OUT OF THE BOX:

De 22 en de 24TVSMART start op in de SATELLIET TV (DVB-S) modus op:

1. After turning ON the Smart TV, you will see "NO SIGNAL" on the screen.

Continued on Page 2.

## 1. TERRESTRESTRIAL (DVB-T) CHANNEL SCAN:

1. Push the “HOME” button of the remote control. You will enter the SMART TV Start menu.





3. In the SMART TV Start menu go to **SOURCE: DVB-T** and use the OK button.
4. On screen “NO SIGNAL” occurs. Push the MENU button on the remote control.
5. You will enter the DVB-T Main menu, go to INSTALLATION and use the OK button.
9. In menu Installation, go to AUTO SEARCH en use the OK button.
10. Select COUNTRY: Netherlands, Belgium or any other.....

### 11. 5V antenna power:


- Before you start the DVB-T channel search, set the 5V antenna power On or Off.
- If you use a PASSIVE DVB-T antenna, set the 5V OFF.
- **If you use an ACTIVE DVB-T antenna, set the 5V ON.**

12. After you have selected the Country go to SEARCH and use OK button.



## 3. CABLE (DVB-C) CHANNEL SCAN:

1. Push the “HOME” button of the remote control. You will enter the SMART TV Start menu.



2. In SMART TV menu, go to SOURCE: DVB-C and use the OK button.
3. On TV screen occurs: “No SIGNAL”.
4. Push the MENU button on the remote control.
5. You enter the Main Menu of the Cable TV, go to INSTALLATION and use the OK button.
6. In menu Installation go to AUTO SEARCH and use the OK button.
7. Select at COUNTRY: Netherlands, Belgium or any other country you are located.
7. Go to SEARCH and push the OK button, the available Cable channels will be downloaded.
8. a. If a ID number is requested, select SCAN MODUS > NETWORK.  
Enter the ID number with 4 numbers. ( Go to ID number, OK, on virtual keyboard, select the 4 numbers ).  
b. If **NO** ID number is requested, select SCAN MODUS > FULL SCAN and go to SEARCH and use OK.  
All Cable channels will be downloaded.

If you now want to set up the SMART TV, please refer to pages 9 to 13 of the user manual.



[service@denson-europe.nl](mailto:service@denson-europe.nl)