



I N S T E O N<sup>®</sup>




**INSTEON Motion Sensor**  
Quick Start Guide

# INSTEON Motion Sensor




## Jumper Settings

To configure settings like Night-Only mode and Light Sensitivity via the INSTEON Hub, ensure jumper five is installed over both pins.



## Sensor Placement

Affix the mount to a surface and slide the mount into the retention slot on the rear of the sensor. Avoid areas of rapid heat change.




---

### Motion Sensor detection areas



## Linking to the Hub

- 1 Follow the on-screen instructions to add your Motion Sensor to the INSTEON Hub.




If not using the Hub, refer to the instructions that came with your product.

2

Remove the back cover and when prompted, press and hold the set button until the status LED begins blinking.



Tap the set button. The status LED will double-blink.




## Configure Alerts

To receive email and text message alerts when motion is detected, switch on alerts from device settings within the INSTEON app.



## Trigger a Scene

Add your Motion Sensor to a scene using the INSTEON Hub and it will control the scene.



## Learn More

For the complete Owner's Manual, video tutorials, product support and more, visit:  
**[insteon.com/support](http://insteon.com/support)**

